ZL8600

English language

Leaflet No. **462812** rev 00



STOP *If you have any questions about this product or issues with installation contact the customer services helpline before returning this product to the store.*

AVF Group Ltd.
Road 30, Hortonwood Ind Est, Telford, Shropshire, TF1 7YE, England.
+44 (0) 1952 670009
0870 0609777 (UK)

AVF Incorporated.
3187, Cornerstone Drive, Mira Loma, CA 91752, USA.
1-800 667 0808 (USA)

Orbital Holdings Inc.
3187, Cornerstone Drive, Mira Loma, CA 91752, USA.
1-800 601 8450 (USA)

1 Boxed Parts



2 Tools Required

3 Fit Screen Brackets

When fitting the screen brackets, fit them close to the top of the TV (without them being visible). This will make hanging the TV and adjusting its level much easier.

Dimension “B” should not be greater than 120mm [4 3/4"].

With small TV’s it may be advantageous to remove the bottom section of the TV brackets as shown in the optional configuration.





Optional configuration
(extension removed)



Choose the screws C1-C5 that suit your TV
Use spacers D1-D2 to space the bracket away from your TV if required



CAUTION!
If "H" is greater than 800mm [31 1/2"] stop installation now and contact the customer help line

4 Determine Wall Bracket Height



5 Fit Bracket To Wall

Use the bracket as a template
Hold the bracket level while marking the wall



Solid Wall



Wood Stud Wall



IMPORTANT!
Ensure all three fixings are on the centre of the wood stud



DO NOT over tighten screws
Tighten screws by hand only

6 Assemble